
10
SWITCHING BACKPLANE
12
20
22
24
SWITCHING INTERFACE 14
26
SWITCHING INTERFACE 16
28
SWITCHING INTERFACE 18
LANs 30
LANs 32
LANs 34

FIG. 1


PACKET SWITCHING CONTROLLER 52
ACCESS CONTROLLER 54
50

FIG. 2



FIG. 3



FIG. 4



FIG. 5


RECEIVE INBOUND PACKET
250
RECEIVE APPLICATION DATA AND PACKET DATA
252
CREATE EDIT PROGRAM
254
STORE EDIT PROGRAM IN IRAM
256
COPY INBOUND PACKET
258
MODIFY INBOUND PACKET
260
TRANSMIT OUTBOUND PACKET
262

FIG. 6